

Guidelines for Laboratory Verification of Performance of QIAstat-Dx[®] Meningitis/Encephalitis Panel

QIAGEN GmbH, QIAGEN Strasse 1, 40724 Hilden, Germany

Introduction

This document provides a sample protocol to verify QIAstat-Dx Meningitis/Encephalitis Panel (cat. no. 691621). The protocol provides positive and negative tests for the pathogens detected by QIAstat-Dx Meningitis/Encephalitis Panel.

Each laboratory is responsible for defining their verification procedure and ensuring that they meet state and federal guidelines.

Materials and methods

The procedure described below and in Table 1 generates multiple positive and negative results for each of the sample control mixes tested. The sample protocol was developed using ZeptoMetrix[®] NATtrol[®] Meningitis/Encephalitis Verification Panel available from ZeptoMetrix Corporation (Buffalo, NY; cat. no. NATMEP-QIA).

If testing is performed using a QIAstat-Dx Analyzer with additional Analytical Modules, the laboratory director may choose not to perform the verification protocol on each Analytical Module. If the complete verification protocol is not performed on each Analytical Module, we advise distributing test replicates evenly among the different Analytical Modules of the system.

Table 1. Overview of sample verification method

Sample code	
Organism controls per sample control mix	4–5
Number of sample control mixes	2
Replicates per sample control mix	4
QIAstat-Dx cartridges required	8
Expected number of positive results	36
Expected number of negative results	36
Approximate days of testing	2
Number of operators	2

Table 2. Materials needed for the sample verification method

Material	Catalog number	Quantity
QIAstat-Dx Meningitis/Encephalitis Panel kit (6 tests)	691621	2
QIAstat-Dx Operational Module	9002813	1
QIAstat-Dx Analytical Module(s)	9002814	1–4
NATtrol Meningitis/Encephalitis Verification Panel	ZeptoMetrix NATMEP-QIA	1
Sample tubes, 2 mL	Sarstedt 72.694.005 (or similar)	4
Filter tips for microliter pipette	Sarstedt 70.3040.255 (or similar)	24

Performance verification materials

The materials listed in Table 2 are required to perform verification with the sample protocol.

Sample verification method

This sample verification method describes how to prepare sample control mixes by mixing together 4–5 different organism controls using a combination of pathogens from the NATtrol Meningitis/Encephalitis Verification Panel. Proposed mixing of organism controls is provided in Table 3. The method tests a total of 2 sample control mixes (2 sample control mixes tested in 4 replicates each). For each assay run, the method provides 4–5 positive results and, correspondingly, 4–5 negative results for the 9 pathogens in total that are detected and differentiated by QIAstat-Dx Meningitis/Encephalitis Panel.

Currently, *M. pneumoniae*, Cytomegalovirus, HSV1, HSV2, HHV6, VZV and Human parechovirus are not part of the panel, and therefore they will not be used.

Any changes to this protocol should take into account additional lab personnel and number of instruments, based on individual laboratory needs.

Mix the organism controls to create control samples at the beginning of the sample verification method. The sample control mixes can be stored at refrigerated conditions (2–8°C) for up to 2 days.

Note: It is important to prepare only the number of sample control mixes that will be tested within 2 days of preparation. The number of samples prepared may be increased or decreased based on the laboratory's work schedule and number of QIAstat Dx Analyzer instruments.

Protocol

Day 1

1. Prepare Sample Control Mix 1 and Sample Control Mix 2 (refer to Table 3).
 - a. Transfer 0.25 mL of each of the organism controls in the mix to a new 2 mL tube using a microliter pipette.
 - b. Ensure the pooled sample is effectively mixed by vortexing prior to testing.
2. Test 2 replicates from Sample Control Mix 1. The duplicate samples should be tested in a single day by different operators (see Table 4).

3. Repeat step 2 for Sample Control Mix 2 to be tested on the same day.
4. Store the samples at 2–8°C for up to 2 days for the evaluation of day-to-day variation.

Day 2

To evaluate day-to-day variation, test the remaining volume of the sample control mixes prepared on Day 1 (Sample Control Mix 1 and Sample Control Mix 2) by repeating steps 2 and 3 above.

Table 3. Proposed organism control mixing and expected positive/negative results

Mix	Organism	Organism control volume (mL)	Final volume of mix (mL)	Expected results	Number of expected negative results
Sample Control Mix 1	<i>N. meningitidis</i>	0.25	1.25	positive	4
	<i>S. agalactiae</i>	0.25		positive	
	<i>L. monocytogenes</i>	0.25		positive	
	<i>H. influenzae</i>	0.25		positive	
	Echovirus Type 11 (Enterovirus target)	0.25		positive	
Sample Control Mix 2	<i>S. pneumoniae</i>	0.25	1.0	positive	5
	<i>S. pyogenes</i>	0.25		positive	
	<i>C. gattii</i>	0.25		positive	
	<i>E. coli</i>	0.25		positive	

Table 4. Workflow for the sample verification method

	Day 1	Day 2
Operator 1	Sample Control Mix 1	Sample Control Mix 1
	Sample Control Mix 2	Sample Control Mix 2
Operator 2	Sample Control Mix 1	Sample Control Mix 1
	Sample Control Mix 2	Sample Control Mix 2

For up-to-date licensing information and product-specific disclaimers, see the respective QIAGEN instructions for use or user manual. QIAGEN instructions for use and user manuals are available at www.qiagen.com or can be requested from QIAGEN Technical Services or your local distributor.

Trademarks: QIAGEN®, Sample to Insight®, QIAstat-Dx® (QIAGEN Group); NATtrol™, ZeptoMetrix® (ZeptoMetrix Corporation). Registered names, trademarks, etc. used in this document, even when not specifically marked as such, may still be protected by law. 01/2025 PROM-23553-001 QPRO-9389 © 2025 QIAGEN, all rights reserved.