Roche[®] LightCycler[®] 480 instrument setup instructions for qBiomarker Copy Number PCR Arrays

Important points before starting

- Please read the handbook supplied with the qBiomarker Copy Number PCR Array, paying careful attention to the "Safety Information" and "Important Notes" sections, before beginning this procedure.
- Make sure the real-time PCR instrument is working properly. Refer to the manufacturer's Installation and Maintenance manual if needed.
- Make sure the correct thermal block cycler (384-well block format for G plate or 96-well for F plate) is in place.
- Turn on the LightCycler 480 instrument; the main switch is located at the back of the instrument. Turn on the computer linked to the instrument and log on to Windows[®] XP.

Procedure

Creation of PCR protocol template

- 1. Start LightCycler 480 software 1.5.0 SP4.
- Enter Username and Password when the Login dialog box appears and click the Ø button to proceed with the login. The "Overview" window will appear.
- 3. Wait for the initiation of the instrument to finish and the two status LEDs on the front of the instrument to become stable. The left LED should become a steady green while the right LED should be a steady orange.
- 4. In the "Overview" window (Figure 1), click the "New Experiment" button on the right-hand side of the window to launch the "Run" module.



Sample & Assay Technologies

innet few	COM_SIST / Standing (or MWP) Overview			mputar (Tcacaable) n Admin	(hec
7	LightCycler® 480 Software Version 15.8.39	release 1.5.0 SP4		Experiment Creditor	Ma. (7) (M
				Rew Experiment	M
		Relative Quantification		Rev Topeleont from Jangian	E
	Gene Scanning	AA		Dyen Tribing Object	1 0 V
	1	Melt Curve Gen	otyping	5	5
	Endpoint Genotyping	Absolute Quantification			
		(Annual Annual Annua	4	5	
	Defermation 1/5/2012 3:10:16 PE Installar Defermation 1/5/2012 3:10:06 PE Installar	stins of Instrument, Fusilegarsony, Detection -	ine.	1	1

Figure 1. "Overview" window.

- 5. In the "Setup" area at the top of the "Run Protocol" tab (Figure 2), specify the following setup parameters:
 - "Detection Format": SYBR[®] Green 1
 - "Block Type": should show the correct block format (384 or 96)
 - "Plate ID": this field is optional
 - "Reaction Volume": 10 µl for G plate or 25 µl for F plate




Figure 2. Initial run protocol window.

- 6. In the "Programs" section, click the 🕑 button twice to add two more program lines.
- 7. Click to change the "Program Name" of the first program to "Heat Activation." Leave the number of "Cycles" at "1", and leave the "Analysis Mode" as "None." In the "Program Temperature Targets" section, enter the values for the following parameters (see Figure 3):

Target (°C)	Acquisition mode	Hold (hh:mm:ss)	Ramp rate (°C/s)	Acquisition (per °C)	Sec target (°C)	Step size (°C)	Step delay (cycles)
95	None	00:10:00	4.8*		0	0	0

*This is the default ramp rate for 384-well block. The default ramp rate for 96-well block is 4.4° C/s.

March Property and	WP)			ase: My Computer (Tro System Admin	iceable)
New Experiment			J User:		
Run Prote	col	Data		Run Notes	
Detection Format SYER Geo	en I	Customize	Block Size 104	Plate ID	Reaction Volume 10
Color Comp ID	Let N		Test II		
	- 0000		1.1997.55		
A Program Name		Programs		Cycl	es Analysis Mode
Reat Activation Program				1	None
				1	None
Program				1	None
Y		14			
~		Program Temperature 1	Targets		
Target (*Q	Acquisition Mode Hold	(hh:mm:ss) Ramp Rate (*Cis)	Acquisitions (per *C)	Sec Target (*C) Step	Size ("C) Step Delay (c)
🛨 🛊 95 🔹 🕅 No	ne • 0011010	0 04.0 0		0 20	0
\sim					
		Overview			
100					
90					
90					
90					
90					
90					
00 00 00 00 00 00 00 00 00 00 00 00 00					
1 anyaanana (0) 0 00 00 00 00 0 00					101
100 000 000 000 000 000 000 000 000 000		Estimated Time (hummes)	1		10.9
90 00 70 60 50 40 30 000		Estimated Time (hummes)		Fad Program	
100 000 000 000 000 000 000 000 000 000		Estimated Time (kmmxes)		End Program	103 10 Cycles

Figure 3. Setup of the first program — "Heat Activation."

8. Click to change the "Program Name" of the second program to "PCR Cycling". Change the number of cycles to "45"** and change the "Analysis Mode" to "Quantification". In the "Program Temperature Targets" section, click the [⊕] button to add one more temperature target line. Enter the values for the following parameters (Figure 4):

Target (°C)	Acquisition mode	Hold (hh:mm:ss)	Ramp rate (°C/s)	Acquisition (per °C)	Sec target (°C)	Step size (°C)	Step delay (cycles)
95	None	00:00:15	1.0		0	0	0
70	Single	00:01:00	1.0		0	0	0

** The PCR is run for extra five cycles (i.e. 45 cycles) rather than the typical 40 cycles indicated in the handbook as this will allow the use of the Second Derivative Maximum method available with the LightCycler 480 software for data analysis. See Data Analysis section for further details.




Figure 4. Setup of the second program — "PCR Cycling."

9. Click to change the "Program Name" of the third program to "Melt Curve." Leave "Cycles" at "1" and change "Analysis Mode" to "Melting Curves." In the "Temperature Targets" section, click the 🕑 button once to add one more temperature target line. Enter the values for the following parameters (Figure 5):

Target (°C)	Acquisition mode	Hold (hh:mm:ss)	Ramp rate (°C/s)	Acquisition (per °C)	Sec target (°C)	Step size (°C)	Step delay (cycles)
60	None	00:00:15	4.8*				
95	Continuous		0.03	20			

* This is the default ramp rate for 384-well block. The default ramp rate for 96-well block is 4.4°C/s.




Figure 5. Setup of the third program — "Melt Curve."

10. Click the down arrow button () right next to the "Apply Template" button on the lower left corner of the screen; select the "Save As Template" button (Figure 6) to save the run template under the filename "CopyNum_PCR_Array_384_LC" if using the 384-well format or "CopyNum_PCR_Array_96_LC" for if using the 96-well format.

New Experiment		User: System Admin
Run Protocol	Date	Run Notes
etection Format SYER Green I		k Size 104 Plate ID Reaction Volume 10
color Comp ID	Let No	Test ID
	Programs	
Program Name		Cycles Analysis Mode
D Reat Activation PCR Cycling		1 None
		45 Quantification
Jeit Curve		1 Belting Curves
/		
Save Template		
Real Root		
Target (*C)	lain .	C) Sec Target (C) Step Size (C) Step Delay (cyc
B 60 Bone Maco	nerti L	a a
A DA COME B MOON	X_POR	4 3 3
E alcono e al alco	x_POR_2	
B-0 S		
8 Speci R Temp	d Diata	
in T teach	and .	
100-		
		11111111111
90		
80]		
70 Name 872_Prot	Lier_PCR_Array_384_LC	
60 UUUUL		
60 UUUUU		\odot
40	1	
30		
0.00.00 0.10.15 0.24.56 0	20:36 0:54.17 1:00:57 1:22 Estimated Time (hommon)	230 1.30.10 1.52.59 2.07.27
	sectore state particular	
Apply Template		End Program + 10 Cycles Start Run

Figure 6. Saving the "Run Template" file.

Performing real-time PCR detection

- 11. After the PCR array is prepared and centrifuged, bring the plate to the LightCycler 480 instrument to load.
- 12. Make sure the correct thermal block (384-well block format for G plate or 96-well for F plate) is in place.
- 13. If the instrument is not on, turn it on using the main switch at the back of the instrument. Turn on the computer linked to the instrument and log on to Windows XP.
- 14. Start LightCycler 480 software.
- 15. Enter "Username" and "Password" when the "Login" dialog box pops up and click the 🙆 button to proceed with the login. The "Overview" window will appear.
- 16. Wait for the two status LEDs on the front of the instrument to become stable. The left LED should become a steady green while the right LED should be a steady orange.

Roche LightCycler 480 real-time PCR setup instructions for qBiomarker Copy Number PCR Arrays

- 17. Press the ←→ open/close button on the front of the instrument (located next to the instrument status LEDs). The plate loading arm will slide out of the right side of the instrument. Place the PCR array plate into the frame of the loading arm with the flat edge of the array closest to the instrument and the edge with a beveled corner pointing away from the instrument.
- Press the ←→ open/close button again to retract the loading arm. Wait for both of the status LEDs to turn steady green.
- 19. In the "Overview" window, click the "New Experiment" button on the right-hand side of the screen.
- 20. In the "Run Protocol" tab, click the "Apply Template" button on the lower left corner of the screen. Select and double click to open the appropriate previously saved "CopyNum_PCR_Array_384_LC" or "CopyNum_PCR_Array_96_LC" run template file.
- Press the "Start Run" button on the lower right corner of the screen to initiate the run. When prompted, save the file under a new filename after which the run will begin.

Data analysis

1. In the "Navigator" window (Figure 7), find and open the run file to be analyzed.




Figure 7. Opening a completed run file.

Roche LightCycler 480 real-time PCR setup instructions for qBiomarker Copy Number PCR Arrays

- 2. For data analysis using the LightCycler 480, use of the "Second Derivative Maximum" analysis method available in this software is highly recommended. This is an algorithm based on the kinetics of a PCR reaction. This method identifies the crossing point (Cp) of a PCR reaction as the point where the reaction's fluorescence reaches the maximum of the second derivative of the amplification curve, which corresponds to the point where the acceleration of the fluorescence signal is at its maximum. Hence, this crossing point should always be located in the middle of the log-linear portion of the PCR amplification plot. The advantage of this analysis method is that it requires little user input and produces consistent results.
- 3. Obtaining the crossing point (Cp) cycle values: Once the selected run file is open, click the "Analysis" button on the left-hand side of the window. In the "Create new analysis" list, double-click to select "Abs Quant/2nd Derivative Max". In the "Create new analysis" window that opens, make sure the Analysis Type is "Abs Quant/2nd Derivative Max" (Figure 8). Click I confirm the selection.




Figure 8. Setting up the analysis for the second derivative maximum.

Roche LightCycler 480 real-time PCR setup instructions for qBiomarker Copy Number PCR Arrays

4. The "Analysis Window" with the amplification curves will appear (Figure 9). To proceed, click the down arrow button (☑) on the lower right corner of the screen to set the analysis to "High Confidence." Next, click the "Calculate" button to generate Cp values. The calculation may take a few minutes.



Figure 9. Obtaining the crossing point (Cp) cycle values at the second derivative maximum.

5. Once the Cp values are generated, move the mouse over to the "Samples" window and click to highlight the samples result table. Right click the table and select "Export" button to export the data. A "Save table data" dialog box will appear (Figure 10). Enter a filename to save the data as a text file. Then click the B button on the right panel to save the second derivative maximum analysis and the Cp values as part of the run file.




Figure 10. Exporting the Cp values.




Figure 11. Setting up the melt-curve analysis.

7. The Analysis window with the raw melt curves will appear (Figure 12). To proceed, click the down arrow button (☑) on the lower right corner of the screen to set the analysis to "SYBR Green I Format". Next click the "Calculate" button. The calculation may take several minutes. Once the melting peaks and Tm values appear, check the specificity of each assay by ensuring the presence of a single melt peak in each well. Then click the ☑ button on the right panel to save the melt curve analysis as part of the run file.




Figure 12. Generating melt-curve analysis.

8. To save the melt peak values: Move the mouse over to the "Samples" window and click to highlight the result table. Right click the "Export" button to export the data. A "Save table data" dialog box will appear (Figure 13). Enter a filename to save the data as a text file.




Figure 13. Exporting the melt curve data.

The qBiomarker Copy Number PCR Arrays are intended for molecular biology applications. These products are not intended for the diagnosis, prevention, or treatment of a disease. For up-to-date licensing and product-specific disclaimers, see the respective QIAGEN kit handbook or user manual. QIAGEN handbooks can be requested from QIAGEN Technical Service or your local QIAGEN distributor. Selected handbooks can be downloaded from <u>www.qiagen.com/literature</u>. Safety data sheets (SDS) for any QIAGEN product can be downloaded from <u>www.qiagen.com/safety</u>.

Trademarks: QIAGEN[®] (QIAGEN Group); LightCycler[®], Roche[®] (Roche); SYBR[®] (Life Technologies Corporation); Windows[®] (Microsoft Corporation). Nov-12 © 2012 QIAGEN, all rights reserved.

www.qiagen.com	France = 01-60-920-930	The Netherlands = 0800 0229592
Australia = 1-800-243-800	Germany = 02103-29-12000	Norway = 800-18859
Austria = 0800/281010	Hong Kong = 800 933 965	Singapore = 65-67775366
Belgium = 0800-79612	Ireland = 1800 555 049	Spain = 91-630-7050
Canada = 800-572-9613	Italy = 800 787980	Sweden = 020-790282
China = 021-51345678	Japan = 03-6890-7300	Switzerland = 055-254-22-11
Denmark = 80-885945	Korea (South) = 1544 7145	UK = 01293-422-911
Finland = 0800-914416	Luxembourg = 8002 2076	USA = 800-426-8157



Sample & Assay Technologies